



# MG-KRETE™

## Application Tips for MG-Krete: Large Pour

- ✓ Always pour the activator “juice” into the mixer first. For example: for a four-bag mix, pour four gallons into mixer first, then add the powder
- ✓ The only way to extend the working time is to use the Retarder in the mix.
- ✓ Always add the Retarder into the juice (when needed), mix for 10-15 seconds
- ✓ If you’re extending the mix with clean dry pea stone, add it into the “juice” now, then mix.
- ✓ When ready, pour in the correct amount of MG-Krete.
- ✓ After the mix is wet, pour out of mixer, clean out as needed, tilt up mixer and add the next amount of “Juice” to keep the mixer wet.
- ✓ When you’re ready for the next mix, add the Retarder (if needed), add pea stone (if using), add MG-Krete.
- ✓ The dryer the mix the easier it is to finish the surface.
- ✓ Fold-up a wet towel, place on the side to periodically clean-off your trowel
- ✓ If you have to grind or shot blast the concrete surface to open the pores, it’s best to pre-spray area with the “Juice”. This absorbs any residual dust.
- ✓ Wetting down the area with the “juice” helps the bonding on ground surface prep.
- ✓ The faster you mix the MG-Krete and get it out of the mixer, the less ammonia smell.
- ✓ Always replace control and expansion joints if applicable.
- ✓ On deeper repairs, always saw cut through the MG-Krete where possible.
- ✓ Never use Retarder in cold temperatures
- ✓ When pour is complete, power wash the mixer with water